

Turn off Attention LED from HMC

Source: <http://unix.derkeiler.com/Mailing-Lists/AIX-L/2005-08/0095.html>

From: Ian Bjorhovde (ian.bjorhovde_at_GMAIL.COM)

Date: 08/16/05

Date: Mon, 15 Aug 2005 17:35:46 -0700
To: aix-l@Princeton.EDU

Hi,

I've been trying to figure out how to turn off the Attention LED for a p5 550 that's attached to an HMC. The hardware information center only references the procedure via ASMI... Is this possible to do while the server is still up?

Thanks,