

FastT Storage Manager

Source: <http://unix.derkeiler.com/Mailing-Lists/AIX-L/2005-09/0090.html>

glh_at_DAIRYNET.COM

Date: 09/19/05

Date: Mon, 19 Sep 2005 13:55:50 -0500
To: aix-l@Princeton.EDU

Last week we installed a DS4300 Turbo (FastT 600). In Storage Manager, under Mappings View, I have twelve AIX hosts defined in a host group called AIX. The twelve hosts are never displayed in alphabetical order. What's the trick to have these twelve hosts displayed alphabetically? I've tried renaming them and / or moving them to a different host group but they never stay alphabetized. Is this a "feature" of Storage Manager?