

Re: logitech cordless optical mouse problems...

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/current/2003-12/2151.html>

From: Philip Paeps (philip+freebsd_at_paeps.cx)

Date: 12/31/03

Date: Wed, 31 Dec 2003 22:43:27 +0100
To: Evren Yurtesen <yurtesen@ispro.net.tr>

On 2003-12-30 17:42:20 (+0200), Evren Yurtesen <yurtesen@ispro.net.tr> wrote:
> *This mouse has a USB connection and PS/2 connection to the computer. The*
> *keyboard works but the mouse doesnt.*

I'm seeing the same thing. When I use the PS/2 converter for the mouse, it works happily, when I use USB, only the keyboard works. The ums driver attaches, but the mouse isn't moving.

I've tried two different mice (both with working batteries and known to be working under psm), and both behave the same way. Which leads me to think the receiver might be the problem, rather than the mouse?

When I plug the thing in, ums and ukbd see the receiver first, which may have something to do with it? It also always finds '5 buttons and Z dir' while my trackman wheel only has three buttons and Z and my mouseman optical has four buttons and Z.

ums0: Logitech USB Receiver, rev 1.10/13.10, addr 2, iclass 3/1
ums0: 5 buttons and Z dir.
ukbd0: Logitech USB Receiver, rev 1.10/13.10, addr 2, iclass 3/1
kbd1 at ukbd0

– Philip

--

Philip Paeps

Please don't CC me, I am
subscribed to the list.

People who love sausage and respect the law should
never watch either one being made.

freebsd-current@freebsd.org mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-current>

To unsubscribe, send any mail to "freebsd-current-unsubscribe@freebsd.org"