

Re: acd0 FAILURE READ_BIG MEDIUM

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/current/2004-10/1851.html>

From: marta (wrig_at_tiscali.it)

Date: 10/19/04

Date: Tue, 19 Oct 2004 16:59:00 +0200

To: freebsd-current@freebsd.org

On Tue, Oct 19, 2004 at 02:19:08AM +0000, cwidger wrote:

```
> >>uname -r
> >>5.3-BETA7
> >>
> >>acd0 : CDRW <qsi CD-RW/DVD-ROM SBW-241/VH04> at ata1-master UDMA33
> >>acd0: FAILURE - READ_BIG MEDIUM ERROR asc=0x00 ascq=0x00 error=0
> >>acd0: FAILURE - READ_BIG MEDIUM ERROR asc=0x00 ascq=0x00 error=0
> >>acd0: FAILURE - READ_BIG MEDIUM ERROR asc=0x00 ascq=0x00 error=0
> >>acd0: FAILURE - READ_BIG MEDIUM ERROR asc=0x00 ascq=0x00 error=0
> >>acd0: FAILURE - READ_BIG MEDIUM ERROR asc=0x00 ascq=0x00 error=0
> >>
> >>This happens when there's a DVD in acd0. It doesn't happen when acd0's
> >>empty.
>
>
> >What kind of DVD drive is it? Did this just start happening with 5.3, or
> >jas it been going on for a while?
>
> I didn't have any problems with 5.2.1, only the 5.3-beta's. It's the built
> in QSI SBW-241 CD-RW/DVD on my Compaq Presario 2100 Laptop.
```

```
uname -r
5.3-BETA7
```

```
sysctl hw.ata.atapi_dma
hw.ata.atapi_dma: 0
```

I have the same laptop and the same problem, I solved using

```
device atapicam
device scbus
device cd
device pass
```

and cutting out

```
device atapicd
```

freebsd-current: Re: acd0 FAILURE READ_BIG MEDIUM

During the bootstrap I have 5/6 sec. of pause, after that
all works well and I can use the DVD drive by the device /dev/cd0

marta

freebsd-current@freebsd.org mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-current>

To unsubscribe, send any mail to "freebsd-current-unsubscribe@freebsd.org"