

freebsd-current: Re: Interrupt storm

Re: Interrupt storm

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/current/2005-03/0891.html>

From: Mike Tanca (*mike_at_sentex.net*)

Date: 03/29/05

Date: Tue, 29 Mar 2005 13:59:28 -0500

To: Dan Cojocar <dan.cojocar@gmail.com>, freebsd-current@freebsd.org

At 01:22 PM 29/03/2005, Dan Cojocar wrote:

>Hello all,

>

>I noticed the following interrupt storm in my dmesg:

>

>Interrupt storm detected on "irq11: rl1"; throttling interrupt source

>Interrupt storm detected on "irq5: rl0"; throttling interrupt source

If you disable USB in the BIOS, does it make the problem go away ? Or, if it is disabled, the dmesg seems to be showing that its still there. Try defining the driver for the USB controller, with USB enabled in the BIOS.

---Mike

freebsd-current@freebsd.org mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-current>

To unsubscribe, send any mail to "freebsd-current-unsubscribe@freebsd.org"