

Re: enabling hyper-threading on intel dual-core

Re: enabling hyper-threading on intel dual-core

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/performance/2006-05/msg00064.html>

- *From:* "OxY" <oxy@xxxxxxxx>
 - *Date:* Thu, 11 May 2006 20:37:38 +0200
-

930 is perfect, fast enough, no need to spend more money, thanks :)

----- Original Message ----- From: "Achim Patzner" <ap@xxxxxxxx>

To: "OxY" <oxy@xxxxxxxx>

Cc: <freebsd-hackers@xxxxxxxx>; <freebsd-performance@xxxxxxxx>

Sent: Thursday, May 11, 2006 8:16 PM

Subject: Re: enabling hyper-threading on intel dual-core

i just bought an Intel Pentium D-930 (3ghz dual-core)
and wonder why i just only have CPU0 and CPU1, when i compile with
SMP...

You would need a Pentium Extreme (840, 955 or 965) for this. And quite a bit of cash.

Achim

freebsd-performance@xxxxxxxx mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-performance>

To unsubscribe, send any mail to "freebsd-performance-unsubscribe@xxxxxxxx"