

Boot Manager – HPT372 Controller

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/questions/2003-05/1192.html>

From: joel b. bintliff (joel_at_lconn.net)

Date: 05/25/03

To: <freebsd-questions@FreeBSD.ORG>

Date: Sun, 25 May 2003 08:53:22 -0500

Hello,

I am trying out the HPT372 Controller with two seagate 80gig IDE drives RAID 1 on FreeBSD 5. The OS installs no problem but there is no boot manager when I try to boot without the boot floppy. I have tried going back into FDISK and selecting the boot manager but it doesn't seem to write to the drive. Any help would be greatly appreciated.

joel

freebsd-questions@freebsd.org mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-questions>

To unsubscribe, send any mail to "freebsd-questions-unsubscribe@freebsd.org"