

Re: D-Link Wireless card

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/questions/2005-08/0429.html>

From: Fabian Keil (freebsd-listen_at_fabiankeil.de)

Date: 08/06/05

Date: Sat, 6 Aug 2005 18:41:26 +0200
To: Beecher Rintoul <akbeech@gmail.com>

Beecher Rintoul <akbeech@gmail.com> wrote:

> *I'm attempting to get a D-Link DWL-AG530 wireless card to work in
> FreeBSD. Since the card is not supported, I fetched and built the
> driver with ndis which built and installed ok. I made sure to use the
> correct winblows XP drivers (I tried them in XP and they work). When I
> kldload the module the card is not recognized at all and does not
> create ndis0. I've scoured the ndis manpages and everything seems
> correct. Has anyone had experience with this?*

Which FreeBSD version?

Did you use ndisgen?

Fabian

--

<http://www.fabiankeil.de/>

- application/pgp-signature attachment: stored