

Re: UDMA ICRC error

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/stable/2003-05/0159.html>

From: Zer0 (ellen.macisaac_at_ns.sympatico.ca)

Date: 05/25/03

Date: Sun, 25 May 2003 11:55:38 -0400

To: freebsd-stable@freebsd.org

Hernani Marques Madeira wrote:

> *Hi@all*
> *On Sunday 25 May 2003 09:15, David A Bestor wrote:*
>
>
>> *I hit this 2 weeks ago when moving an 8gig to a 60 gig...*
>> *I had the errors on the new 60gig. The errors went away*
>> *when I changed the cable. It was connected on the IDE100*
>> *slot. I changed the cable to the proper cable for that*
>> *slot and that fixed it. I found the answer in a google*
>> *search.*
>>
>
>
> *Yes, i can confirm that. I also changed the cables & found the answer*
> *on groups.google.com, too*
> *If you've bought a built pc-system it often happens that the cables*
> *are of poor quality what would result in a falling back to PIO mode.*
> *This seems to be the effect of the low data integrity that is reached*
> *in conjunction with those cables.*
>
> *Hernani*
>
>
Cable swapping did nothing to resolve my problem (that was the first thing I tried) I also tried setting the DMA mode manually in the BIOS ...no dice.

freebsd-stable@freebsd.org mailing list

<http://lists.freebsd.org/mailman/listinfo/freebsd-stable>

To unsubscribe, send any mail to "freebsd-stable-unsubscribe@freebsd.org"