

Re: USB support + Supermicro IPMI KVM = no keyboard

Source: <http://unix.derkeiler.com/Mailing-Lists/FreeBSD/stable/2008-01/msg00728.html>

- *From:* "Steven Hartland" <killing@xxxxxxxxxxxxxxxxxx>
 - *Date:* Tue, 29 Jan 2008 13:46:42 -0000
-

----- Original Message ----- From: "Max Laier" <max@xxxxxxxxxxxxxxxxxx>
On Tuesday 29 January 2008, Steven Hartland wrote:

So two questions:-

1. Can usb support be disabled from the loader?
2. Anyone got any ideas why USB would break the IPMI keyboard?

You could try `hint.kbdmux.0.disabled="1"` – see `kdbmux(4)` for details.

Thanks for the idea Max no go unfortunately, also tried:-

`hint.usb.0.disabled=1`
`hint.uhci.0.disabled=1`
`hint.ohci.0.disabled=1`
`hint.ukbd.0.disabled=1`

Regards
Steve

=====

This e.mail is private and confidential between Multiplay (UK) Ltd. and the person or entity to whom it is addressed. In the event of misdirection, the recipient is prohibited from using, copying, printing or otherwise disseminating it or any information contained in it.

In the event of misdirection, illegible or incomplete transmission please telephone +44 845 868 1337 or return the E.mail to postmaster@xxxxxxxxxxxxxxxxxx

freebsd-stable@xxxxxxxxxxxxx mailing list
<http://lists.freebsd.org/mailman/listinfo/freebsd-stable>
To unsubscribe, send any mail to "freebsd-stable-unsubscribe@xxxxxxxxxxxxx"