

280R serial port

Source: <http://unix.derkeiler.com/Mailing-Lists/SunManagers/2004-10/0165.html>

Chris.CTR.Schroen_at_faa.gov

Date: 10/15/04

To: sunmanagers@sunmanagers.org

Date: Thu, 14 Oct 2004 18:48:20 -0400

This one's got me stumped. I inherited a SunFire 280R. I can get into the RSC serial port no problem, but I don't have a username/password (I tried "admin/admin") to log in and interact with the RSC shell.

Serial A & B are DB-25 ports. I have a DB-25 null modem cable that works fine on a V880, but no joy here. Is that because "input-device" and "output-device" are set to "rsc-console"? Am I wasting my time even trying to get in via Serial A if RSC's been set up?

If "input-device" and "output-device" have been set to "rsc-console," is there any way to get to the "ok" prompt other than via RSC? How do I boot the system if I can't even get to the "ok" prompt? I don't mind reinstalling Solaris; I'm probably going to do so anyways, but how can I get into this thing?

=====

Chris Schroen
UNIX System Administrator
FAA (ATO-A)/AMTI
tel +1 703 841 2230
fax +1 703 841 1458
mailto:chris.ctr.schroen@faa.gov

sunmanagers mailing list
sunmanagers@sunmanagers.org
<http://www.sunmanagers.org/mailman/listinfo/sunmanagers>